













# Datalogic Magellan 3200VSi



1	 Standard Product Default Settings
2	 Enter/Exit Programming Mode
3	 60msec
4	 Low

## Datalogic Magellan 3200VSi

5	 <p>USB COM Interface</p>
6	 <p>Enable Interleaved 2 of 5</p>
7	 <p>Enable QR Code</p>
8	 <p>2D Read Mode = Reads both normal and inverse labels</p>

9	 Label ID Transmission: Disable
10	 Set Prefix
11	 0
12	 2

13	 Enter/Exit Programming Mode
14	 Set Suffix
15	 0
16	 3

17	 Enter/Exit Programming Mode
18	 Enter/Exit Programming Mode