

Honeywell Genesis 7580g

Tastatur-Modus

05.06.2024



Resetting the Factory Defaults: Activate Defaults

Presentation Aimer Mode: Interlaced

Cellular Telephone Reading Mode: On

Program Keyboard Country: Germany

Dead Key Thru Alt+Numpad Sequence: Windows System Code Page

Prefix: STX

Suffix: ETX

Keyboard Modifiers: Windows Mode Control + X



DEFAULT;PDCAIM2;KBDCTY4;KBDALT4;HSTACH18;HSTDCH20;DECCEL1;PREBK29902;SUFBK29903;KBDCAS2.